

WATCH DOG

REAL-TIME PROPERTY TRACKING

Description

The **WD-1000 & WD-1000-ODB Real-Time Property Tracking Device** uses the latest GPS technology to help provide the peace of mind that your car, truck, boat, or trailer is where you think it is. It incorporates the latest web based GPS technology to alert you via an email or a text message when your vehicle has been moved without your authorization and allows you to immediately locate it to aid its recovery. The **WD-1000 & WD-1000-ODB** is perfect for that added security of your high dollar toys as well as your daily driver.



WD-1000

Features

- Web Based/GPS Platform
- Locate on Demand
- Six Programmable Geo-Fences
- Enter/Exit Geo-Fence Notification
- Map and Satellite Imagery
- 500 Locate/3 Year Tracking Included
- Email/Text Alert
- Easy Installation
- 12 VDC Wired Connection (WD-1000)
- OBDII connection (WD-1000-ODB)

Applications

- Race Cars
- Automobiles
- Trailers (power must be provided)
- Trucks
- Boats
- Motorcycles
- Any motorized vehicle that uses 12 VDC for power

Specifications

Power: 12 VDC
Cellular Service: (Included)
Locations/Alerts: 500 (Included)*
(for up to three years)

Dimensions: 1.75" x 1.0" x 2.0"
(5.0 x 2.5 x 4.5 cm)
Weight: 1.34 oz (38g)
Warranty: 1 year

Ordering Information:

WD-1000	WatchDog™ Web Based GPS Real-Time Property Tracker
WD-1000-ODB	WatchDog™ Web Based GPS Real-Time Property Tracker with OBDII Connection

WatchDog™ Installation and Operation Instructions

Installation Instructions (WD-1000)

1. Locate and connect the red wire to a constant 12 VDC voltage source (Fuse panels are a good place to start).
2. Connect the black wire to a solid ground. (Look for bolts connected to the chassis for the best ground)
3. Once the power and ground wires are connected , plug the WatchDog™ into the harness.
4. Verify that you have either a solid or flashing green light, and a blinking blue light. The presents of both lights indicates proper wiring. **Green LED:** Solid – No GPS, Flashing – Good GPS; **Blue LED:** 1 Flash On, 3 Count Off – Good Cellular Coverage, 1 Flash On, 1 Count Off – No Cellular Coverage.
5. If no GPS is indicated please move WatchDog™ to another position, and repeat until you get a good connection. Please allow 5 minutes for GPS acquisition.
6. Once a good location has been found, secure the WatchDog™ to the vehicle with wire ties, velcro, or double sided tape (included). Be sure to mount the WatchDog™ with the label side down.
7. Skip to step 1 of the “Quick Setup” procedure below.

Installation Instructions (WD-1000-OBD)

1. Locate your OBDII connection and with the car switched off plug the WD-1000-OBD into the OBDII connector.
2. Proceed to the “Quick Setup” procedure below.

Quick Setup

1. Install according to instructions (see above)
2. Note the serial number on the outside of the unit
3. Go to www.mobilesecurezone.com (<http://trak.sattrackgps.com> for WD-1000-OBD) and register your WatchDog™ (Note: in the setup process be sure to select the 3 yr option with 500 locations)
4. Go to commands and set up your geo-fence and other parameters (Note: setting up a Geo-Fence and receiving an alert will activate one location once that alert is sent out.)
5. Locate your device and test out the WatchDog™
6. Your device is now ready to use. (Note: This device does not take the place of prudent and security oriented behavior)

Dimensions & Wiring (WD-1000 only)

